


# Body Side Outer Panel Sectioning (Rear Section)

## Removal Procedure




The replacement outer body side is serviced as a complete assembly. It is necessary to remove and replace the upper fender rails and the rear outer wheel house panel in order to replace the outer body side panel.

The upper fender rails and the outer wheelhouse panels are not included and must be ordered separately.

Sectioning procedures have been developed for the front or the rear of the body side panel as a cost-effective alternative to complete replacement.

**Caution:** Refer to [Approved Equipment for Collision Repair Caution](#) in Cautions and Notices.

1. Disable the SIR system. Refer to [SIR Disabling and Enabling](#) in SIR.
2. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) in Engine Electrical.




**Important:** When replacing the rear section of the outer body side assembly, first remove the rear outer wheel house panel. Depending on the extent of the damage, you may section the outer wheel house panel in the designated area, or replace the entire outer wheel house.

3. Remove all related panels and components including the outer wheel house panel. Refer to [Wheelhouse Replacement - Rear Outer](#) .
4. Repair as much of the damage as possible to factory specifications. Refer to Door Opening and Roof Stowage Dimensions in [Dimensions - Body](#) .


**Caution:** Refer to [Foam Sound Deadeners Caution](#) in Cautions and Notices.

5. Note the location and remove the sealers and anti-corrosion materials from the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#) in Paint and Coatings.




**Important:** Do NOT damage any inner panels or reinforcements.

6. Cut the rocker panel within the shaded area (1) where sectioning is to be performed.




**Important:** Do NOT damage the inner panels or the reinforcements.

7. Locate and drill out all factory welds on the outer body side, rearward of the sectioning cut location. Note the number and location of the welds for installation of the outer body side service part.




8. Verify the existence of structural weld-through adhesive. Refer to [Structure Adhesive - Identification](#) . If necessary use a chisel to separate the body side section from the adjacent panels.




9. Remove the damaged outer body side section.

## Installation Procedure




1. Cut the replacement body side section in corresponding locations to fit the original panel. The sectioning joint should be trimmed to allow  $1\frac{1}{2}$  times the metal thickness at the sectioning joint.
2. Create a 100 mm (4 in) backing plate (A) from the unused portion of the service part. Trim the backing plate as necessary to fit behind the sectioning joint.




3. Drill 8 mm (5/16 in) plug weld holes in the service part as necessary in the locations noted from the original panel and along the sectioning cut.

4. Replace the structural adhesive with an additional plug weld between the existing plug welds where necessary.




5. Drill 8 mm (5/16 in) plug weld holes along the sectioning cut on the remaining original part. Locate these holes 25 mm (1 in) from the edge and spaced 40 mm (1½ in) apart.
6. Prepare all attachment surfaces as necessary.
7. Apply GM-approved Weld-Thru Coating or equivalent to all mating surfaces. Refer to [Anti-Corrosion Treatment and Repair](#) .
8. Fit the backing plate halfway into the sectioning joint, clamp and plug weld to the vehicle.



9. Position the body side section. Refer to Door Opening and Roof Stowage in [Dimensions - Body](#) .

10. Plug weld accordingly.



**Important:** To create a solid weld with minimum heat distortion make 25 mm (1 in) stitch welds along the seam with 25 mm (1 in) gaps between them. Then go back and complete the stitch weld.

11. Stitch the weld sectioning joint.
12. Install all related panels including the outer wheelhouse panel. Refer to [Wheelhouse Replacement - Rear Outer](#) .
13. Clean and prepare all welded surfaces.
14. Apply the sealers and anti-corrosion materials to the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#) in Paint and Coatings.
15. Paint and repair the area. Refer to [Basecoat/Clearcoat Paint Systems](#) in Paint and Coatings.
16. Install all related components.
17. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) in Engine Electrical.
18. Enable the SIR system. Refer to [SIR Disabling and Enabling](#) in SIR.